



Kress



SAFETY AND OPERATING MANUAL

KA3707

A**B**

PRODUCT SAFETY



WARNING: Read all safety warnings and all instructions. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

OPERATING INSTRUCTIONS

Charging (See Fig. A, B)

For use only with all Kress backpack batteries.

For use only with KA3706 KA3712 KA3713 KA3714 chargers.

CHARGING TIPS

- Always check the adaptor for proper condition and connection.
- Never connect the adaptor with damaged battery packs or chargers. Check the battery pack and the charger before connection.
- Straighten the twisted cord before use. Do not pull or twist the cord when charging.
- Always position and secure the adaptor to reduce the risk of injury from tripping on it.
- Disconnect the adaptor from the battery pack and the charger before storage

NOTE: Press the battery pack release button before removing the adaptor from the battery pack. (See Fig. B)

- Never use water or chemical cleaners to clean your adaptor. Wipe clean with a dry cloth.

Positec Australia Pty Limited
10 Corporate Blvd Bayswater , VIC 3153, Australia

Kress 

Copyright © 2025, Positec. All Rights Reserved.
AR01822100